



PS32

## Rechargeable System Instructions

### IMPORTANT SAFETY INSTRUCTIONS SAVE THESE INSTRUCTIONS

**CAUTION:** Risk of electrical shock. Dry location use only. Batteries may become hot to touch while charging.

#### WARNING:

- Charge only rechargeable nickel metal hydride (NiMH) batteries in this charger.
- **Never charge regular, single use alkaline batteries.**
- Never charge rechargeable alkaline or rechargeable nickel cadmium (NiCd) batteries in this charger.
- Charging the wrong batteries in the charger, or mixing battery types in the charger, may cause them to become hot, leak or rupture, causing personal injury.
- Batteries may become warm when charging. This is normal.
- To reduce the risk of electric shock, unplug the charger from the outlet before cleaning. Never immerse the charger in water or any other liquid. For indoor use only. Do not expose the charger to rain or snow.
- Never disassemble the charger or alter the plug. Improper reassembly or connection can result in the risk of electrical shock.
- **DO NOT USE RECHARGEABLE BATTERIES IN SMOKE DETECTORS.**

**DANGER-TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, CAREFULLY FOLLOW THESE INSTRUCTIONS**

#### SAVE THESE INSTRUCTIONS

For connection to a power supply not in the U.S.A, use an attachment plug adapter of the proper configuration for the power outlet.

#### Operating Instructions

1. **Load batteries into charger.**
    - a. Charge either 2 or 4 AA or AAA batteries at a time (they must be charged in pairs). For AA batteries, use the (-) contacts at the very bottom of the unit. For AAA batteries, use the smaller metal (-) contacts that are higher up.
    - b. When inserting the batteries, make sure the + and - end of the batteries are aligned according to the polarity marks (+ and -) on the charger.
    - c. Make sure that the battery is aligned properly in the slot and that each end of the battery is touching the contacts in the charger.
  2. **Plug the charger into the wall socket.**
    - a. Flip up the plug on the back of the charger until it is fully extended.
    - b. Use the standard 110-120 volt AC outlet.
- NOTE:** Place charger in a vertical or floor mount position
3. **LED lights indicate charging.**
    - a. There are 2 LED's on the charger. The LED lights will shut off when charging is complete.
    - b. Unplug the charger when not in use and remove the batteries.

Questions? Call 1-800-237-7000 or visit [www.rayovac.com](http://www.rayovac.com)

## Rechargeable System Instructions

**CONSIGNES DE SÉCURITÉ IMPORTANTES  
CONSERVEZ CES DIRECTIVES**

**CAUTION:** Risque de choc électrique. Utiliser au sec seulement. Les piles peuvent devenir chaudes au toucher pendant la recharge.

**MISE EN GARDE :**

- Rechargez uniquement des piles à hydrure métallique de nickel (NiMH) dans ce chargeur.
- **Ne rechargez jamais des piles alcalines jetables.**
- Ne rechargez jamais des piles alcalines rechargeables ou au nickel-cadmium (NiCd) dans ce chargeur.
- Si vous tentez de recharger le mauvais type de piles dans ce chargeur ou de recharger en même temps des piles de type différent, les piles peuvent devenir brûlantes, elles peuvent couler ou se fendre et causer des blessures.
- Les piles s'échauffent pendant la recharge, ce qui est normal.
- Pour réduire le risque de choc électrique, débranchez le chargeur avant de le nettoyer. Ne plongez jamais le chargeur dans l'eau ou tout autre liquide. Pour utilisation à l'intérieur seulement. Évitez d'exposer le chargeur à la pluie et à la neige.
- Ne démontez jamais le chargeur et ne tentez pas de modifier la fiche. Un montage ou un raccord fautif pourrait causer un choc électrique.
- **N'UTILISEZ PAS DE PILES RECHARGEABLES DANS UN DÉTECTEUR DE FUMÉE.**

**DANGER - AFIN DE RÉDUIRE LE RISQUE D'INCENDIE OU DE CHOC ÉLECTRIQUE, SUIVEZ ATTENTIVEMENT CES DIRECTIVES**

**CONSERVEZ CES DIRECTIVES**

Pour brancher l'appareil dans une prise ailleurs qu'aux États-Unis, utilisez un adaptateur convenant à la prise de courant en question.

**Mode d'emploi****1. Insérez les piles dans le chargeur.**

- a. Rechargez 2 ou 4 piles AA ou AAA à la fois (elles doivent être rechargées deux par deux). Dans le cas des piles AA, utilisez les contacts (-) situés tout au fond de l'appareil. Dans le cas des piles AAA, utilisez les plus petits contacts (-) métalliques situés plus haut.
- b. Insérez les piles en faisant correspondre les pôles + et - des piles aux marques de polarité + et - sur le chargeur.
- c. Assurez-vous que les piles sont bien alignées dans leur compartiment et que chaque extrémité touche les contacts du chargeur.

**2. Branchez le chargeur dans une prise murale.**

- a. Soulevez complètement la fiche à l'arrière du chargeur.
- b. Utilisez une prise électrique standard de 110-120 volts c.a.

**REMARQUE :** Tournez le chargeur de manière à le brancher à la verticale ou dans une prise au sol.

**3. Les voyants lumineux indiquent l'état de la recharge.**

- a. Le chargeur comporte 2 voyants lumineux qui s'éteignent lorsque la recharge est terminée.
- b. Retirez les piles du chargeur et débranchez ce dernier lorsque vous ne vous en servez pas.

Des questions? Composez le 1-800-237-7000 ou visitez le site [www.rayovac.com](http://www.rayovac.com)

RAYOVAC est une marque déposée de ROVCAL, INC.

Dist. par: Spectrum Brands, Inc., Madison, WI 53711

6/06 Job# CS31493 T2208599